

Preisliste / Katalogbeilage - 2011-08

Rhodes

RHO M7-61A.GBK	Rhodes Mark 7 Piano 61 Keys A(Activ) Glossy black	3'440.-
RHO M7-61A.GRD	Rhodes Mark 7 Piano 61 Keys A(Activ) Glossy red	3'440.-
RHO M7-61A.GWH	Rhodes Mark 7 Piano 61 Keys A(Activ) Glossy white	3'440.-
RHO M7-61A.RBK	Rhodes Mark 7 Piano 61 Keys A(Activ) RoadT. Glossy black	4'560.-
RHO M7-61A.RRD	Rhodes Mark 7 Piano 61 Keys A(Activ) RoadT. Glossy red	4'560.-
RHO M7-61M.GBK	Rhodes Mark 7 Piano 61 Keys AM(Activ MIDI) Glossy black	5'080.-
RHO M7-61M.GRD	Rhodes Mark 7 Piano 61 Keys AM(Activ MIDI) Glossy red	5'080.-
RHO M7-61M.GWH	Rhodes Mark 7 Piano 61 Keys AM(Activ MIDI) Glossy white	5'080.-
RHO M7-61M.RBK	Rhodes Mark 7 Piano 61 Keys AM(Activ MIDI) RoadT. black	5'190.-
RHO M7-61M.RRD	Rhodes Mark 7 Piano 61 Keys AM(Activ MIDI) RoadT. red	5'190.-
RHO M7-61S.GBK	Rhodes Mark 7 Piano 61 Keys S(Standard) Glossy black	3'830.-
RHO M7-61S.GRD	Rhodes Mark 7 Piano 61 Keys S(Standard) Glossy red	3'830.-
RHO M7-61S.GWH	Rhodes Mark 7 Piano 61 Keys S(Standard) Glossy white	3'830.-
RHO M7-61S.RBK	Rhodes Mark 7 Piano 61 Keys S(Standard) Road Touch black	3'960.-
RHO M7-61S.RRD	Rhodes Mark 7 Piano 61 Keys S(Standard) Road Touch red	3'960.-
RHO M7-73A.GBK	Rhodes Mark 7 Piano 73 Keys A(Activ) Glossy black	4'470.-
RHO M7-73A.GRD	Rhodes Mark 7 Piano 73 Keys A(Activ) Glossy red	4'470.-
RHO M7-73A.GWH	Rhodes Mark 7 Piano 73 Keys A(Activ) Glossy white	4'470.-
RHO M7-73A.RBK	Rhodes Mark 7 Piano 73 Keys A(Activ) RoadT. black	4'590.-
RHO M7-73A.RRD	Rhodes Mark 7 Piano 73 Keys A(Activ) RoadT. Glossy red	4'590.-
RHO M7-73M.GBK	Rhodes Mark 7 Piano 73 Keys AM(Activ MIDI) Glossy black	5'190.-
RHO M7-73M.GRD	Rhodes Mark 7 Piano 73 Keys AM(Activ MIDI) Glossy red	5'190.-
RHO M7-73M.GWH	Rhodes Mark 7 Piano 73 Keys AM(Activ MIDI) Glossy white	5'190.-
RHO M7-73M.RBK	Rhodes Mark 7 Piano 73 Keys AM(Activ MIDI) RoadT. black	5'330.-
RHO M7-73M.RRD	Rhodes Mark 7 Piano 73 Keys AM(Activ MIDI) RoadT. red	5'330.-
RHO M7-73S.GBK	Rhodes Mark 7 Piano 73 Keys S(Standard) Glossy black	3'990.-
RHO M7-73S.GRD	Rhodes Mark 7 Piano 73 Keys S(Standard) Glossy red	3'990.-
RHO M7-73S.GWH	Rhodes Mark 7 Piano 73 Keys S(Standard) Glossy white	3'990.-
RHO M7-73S.RBK	Rhodes Mark 7 Piano 73 Keys S(Standard) Road Touch black	4'100.-
RHO M7-73S.RRD	Rhodes Mark 7 Piano 73 Keys S(Standard) Road Touch red	4'100.-
RHO M7-88A.GBK	Rhodes Mark 7 Piano 88 Keys A(Activ) Glossy black	5'720.-
RHO M7-88A.GRD	Rhodes Mark 7 Piano 88 Keys A(Activ) Glossy red	5'720.-

RHO M7-88A.GWH	Rhodes Mark 7 Piano 88 Keys A(Activ) Glossy white	5'720.-
RHO M7-88A.RBK	Rhodes Mark 7 Piano 88 Keys A(Activ) RoadT. black	5'850.-
RHO M7-88A.RRD	Rhodes Mark 7 Piano 88 Keys A(Activ) RoadT. Glossy red	5'850.-
RHO M7-88M.GBK	Rhodes Mark 7 Piano 88 Keys AM(Activ MIDI) Glossy black	6'240.-
RHO M7-88M.GRD	Rhodes Mark 7 Piano 88 Keys AM(Activ MIDI) Glossy red	6'240.-
RHO M7-88M.GWH	Rhodes Mark 7 Piano 88 Keys AM(Activ MIDI) Glossy white	6'240.-
RHO M7-88M.RBK	Rhodes Mark 7 Piano 88 Keys AM(Activ MIDI) RoadT. black	6'360.-
RHO M7-88M.RRD	Rhodes Mark 7 Piano 88 Keys AM(Activ MIDI) RoadT. red	6'360.-
RHO M7-88S.GBK	Rhodes Mark 7 Piano 88 Keys S(Standard) Glossy black	5'210.-
RHO M7-88S.GRD	Rhodes Mark 7 Piano 88 Keys S(Standard) Glossy red	5'210.-
RHO M7-88S.GWH	Rhodes Mark 7 Piano 88 Keys S(Standard) Glossy white	5'210.-
RHO M7-88S.RBK	Rhodes Mark 7 Piano 88 Keys S(Standard) Road Touch black	5'330.-
RHO M7-88S.RRD	Rhodes Mark 7 Piano 88 Keys S(Standard) Road Touch red	5'330.-
RHO ZMUSTER.PNO	Rhodes Vorlage Piano	0.-
	334 Rhodes diverses	
RHO XC-61	Rhodes Traveling Case 61	760.-
RHO XC-73	Rhodes Traveling Case 73	790.-
RHO XC-88	Rhodes Traveling Case 88	870.-
RHO XCSP-61	Rhodes Traveling Case SP 61	1'030.-
RHO XCSP-73	Rhodes Traveling Case SP 73	1'130.-
RHO XCSP-88	Rhodes Traveling Case SP 88	1'230.-
RHO XS1-73.BK	Rhodes Speaker Platform 1000 73 Keys Road Touch. 2x500 W. black	2'560.-
RHO XS1-73.RD	Rhodes Speaker Platform 1000 73 Keys Road Touch. 2x500 W. red	2'560.-
RHO XS1-73.WH	Rhodes Speaker Platform 1000 73 Keys Road Touch. 2x500 W. white	2'560.-
RHO XS1-88.BK	Rhodes Speaker Platform 1000 88 Keys Road Touch. 2x500 W. black	2'960.-
RHO XS1-88.RD	Rhodes Speaker Platform 1000 88 Keys Road Touch. 2x500 W. red	2'960.-
RHO XS1-88.WH	Rhodes Speaker Platform 1000 88 Keys Road Touch. 2x500 W. white	2'960.-
RHO XSPSYS	Rhodes Speaker Syst. pair of cabinet	5'780.-
RHO XTELST	Rhodes Telis Stand	580.-